

Rasper belt drive

Being the first step in the wet process, the milling performance is crucial. The yield of the rasper determines to a great extent the overall yield of the entire starch operation. Any starch loss in this section is lost forever.

The starch granules are locked in the cells of the root together with other constituents and have to be released from the cell compound. The more thoroughly the cells are destroyed, the better the release of the granuels, thus the better the starch yield.

SiccaDania raspers are designed to rupture the cell walls so efficiently that the maximum amount of starch from the cassava root is released.

Advanced two piece rotor bearing design

- Flexible house mounting
- Automatic accurate alignment
- Easy replacement, service & maintenance
- Heavy load resistant

Superior saw blades clamping design

- Instant saw blade exchange
- Solid clamping
- $\boldsymbol{\cdot}$ Easy service and maintenance

High speed rotor (2.100 RPM)

Highest milling efficiency



Double cutter block & reversible rotation

- Constant and smooth milling performance
- Long saw blades life time

Full stainless steel

Best-in-Class durability



Technical data



| Model | HRD 300 | HRD 400 | HRD 500 | HRD 600 |
|--------|---------|---------|---------|---------|
| A (mm) | 1190 | 1190 | 1190 | 1300 |
| B (mm) | 2170 | 2170 | 2170 | 2170 |
| C (mm) | 1090 | 1190 | 1285 | 1580 |

| Model | HRD 300 | HRD 400 | HRD 500 | HRD 600 |
|-------------------------|---------|---------|---------|---------|
| Netto load (kg) | 3000 | 3000 | 3400 | 3400 |
| Capacity potatoes (t/h) | 9 | 12 | 30 | 40 |
| Capacity roots (t/h) | 5 | 12 | 17 | 22 |

Spare parts

Sieve plate

Clamping bar

Cutter block

Bearing

V-belt

Swing bar







Labyrinth ring













Rotor





Saw blade



Rasper direct drive

Being the first step in the wet process, the milling performance is crucial. The yield of the rasper determines to a great extent the overall yield of the entire starch operation. Any starch loss in this section is lost forever.

SiccaDania raspers are designed to rupture the cell walls so efficiently that the maximum amount of starch from the root is released. The starch granules are locked in the cells of the root together with other constituents and must be released from the cell compound.

This version is compact and can be easily fitted into an existing milling location. The V-belt drive is easily accessible and provides a steady headache-free operation.

Advanced two piece rotor bearing design

- Flexible house mounting
- Automatic accurate alignment
- Easy replacement, service & maintenance
- Heavy load resistant

Superior saw blades clamping design

- Instant saw blade exchange
- Solid clamping
- $\boldsymbol{\cdot}$ Easy service and maintenance

High speed rotor (2.100 RPM)

Highest milling efficiency



Double cutter block & reversible rotation

- Constant and smooth milling performance
- Long saw blades life time

Full stainless steel

Best-in-Class durability



Technical data



| Model | HRD 600DD |
|--------|-----------|
| A (mm) | 1140 |
| B (mm) | 2840 |
| C (mm) | 1280 |

| Model | HRD 300 |
|-------------------------|---------|
| Netto load (kg) | 4200 |
| Brutto (kg) | 4392 |
| Dynamic load (kg) | 5710 |
| Capacity potatoes (t/h) | 40 |
| Capacity roots (t/h) | 22 |

Spare parts

Sieve plate

Clamping bar

Cutter block

Bearing

V-belt

Swing bar









Cutter block sealing







-

Rotor







Rasper BOSS 6000 DD

The rasper, type SD600 DD has been designed for the highest starch extraction in combination with a robust design and excellent maintenance features. The purpose is to open the tuber cells and release the starch granules. The slurry obtained can be considered a mixture of pulp (cell walls), fruit juice and starch. With this modern highspeed rasper, rasping is a one-pass operation.

The overall design of the rasper is slim and easy to operate and maintain. The rasper has a large rotor diameter, that incorporates the 160 groove profiles for the rasping blades and makes it possible to place a high amount of saw blades in the rotor. This amount of saw blades is determined as an optimum between a longer uptime on one side against the replacement time and the price of sawblades on the other side.

Rotor

- Robust design
- Equipped with 160 sawblades
- Lower maintenance cost
- $\boldsymbol{\cdot}$ Easy accessible with hydraulic cover

Motor drive

- Direct drive to the rotor by means of a belt coupling
- Reversible rotor
- Motor and rotor are mounted on a common high hygienic frame made of stainless steel

Shaft/bearings

- Standard Bearings
- Excellent sealing protection



Advantages

- Easiest maintenance in the market
- Highest hygienic level design in the market
- · A reversible rotor increases the saw blades lifetime
- Stable construction, no foundation bolts required
- High efficient starch extraction
- Direct drive reduced power consumption

Technical data

The rasper is available in widths from 400 up to 600 mm and with motor sizes up to 315 kW.

Potato/Sweet potato

| Model | 600 | 600 |
|----------------|------|------|
| Power (kW) | 250 | 315 |
| Capacity (t/h) | 40 | 52 |
| Weight (kg) | 8100 | 8200 |

Tapioca/yams

| Model | 600 | 600 |
|----------------|------|------|
| Power (kW) | 250 | 315 |
| Capacity (t/h) | 22 | 30 |
| Weight (kg) | 8100 | 8200 |

Maintenance

Easy maintenance results in less downtime.

The rasping blades can rapidly be replaced from the front by the hydraulic easy-open cover. The bottom plate can be inspected and replaced easily and fast without disconnecting the heavy rasper block.





2